Specification

Product name	Philips smart drying rack SDR105
Product model	SDR105-LBW
Dimensions of product	2,230×530×160 mm
Dimensions of host	1,311×328×80 mm
Hole spacing of installation template	1,130×170mm
Pole length	1,260-2,230mm
Dropping distance	0-1,110 mm
Input voltage	220 V ~ 50 Hz
Rated power of product	580 W
Rated power of LED lamp	16 W
Rated power of disinfection	7 W*2
Rated power of air drying	6.5 W*2
Rated power of heat air drying	300 W±10%*2
Rated power of DC motor	60 W
Load capacity	41 kg
Operating temperature	-15-43℃
Operating humidity	10%-90% RH, (Non-condensing)
Noise (Sound Pressure Level)	<55 dB
Quality standard	QB/T 5202-2017

Note: please use CTN to search the product at Philips official website.

Packing list

No.	Item	Qty	Unit	No.	Item	Qty	Unit
1	Host	1	PC	9	Base of bed sheet poles	1	PC
2	Scissor frame assembly	2	set	10	Rubber ring for poles	1	pack
3	Clothes pole	2	PC	11	Set screw for scissor frame	2	PC
4	Bed sheet pole	2	PC	12	M8 expansion screw	4	set
5	Remote control	1	PC	13	User manual/Warranty card	1	PC
6	End cover	2	set	14	Quality certificate	1	PC
7	Joint bar cover	4	PC	15	Installation template	1	PC
8	Joint bar	4	PC				

Please check carefully after unpacking. If there is any item missing, please make timely contact with Philips or Philips authorized service center to obtain it

Notice to users

- $\blacklozenge \ \ \, \text{Ceiling for installation should be solid enough to have expansion screws firmly fixed.}$
- For your safety, please make sure the power supply is grounded and only use power supply indicated on this product. Do not use power supply cable smaller than 0.75
- $\ \, \blacklozenge \,$ To ensure normal operation of the product, please make sure the host is installed at locations away from leaking and rain
- ◆ Do not use the product during thunderstorms.
- ◆ Do not put hands or any other object into scissor frame when the drying rack is • For your health and safety, please do not stare directly at the disinfection UVC light.
- ♦ If batteries are not used for a long period of time, it is recommended to remove it
- from remote control in case of leakage and damage. Avoid mixing old batteries with • For any maintenance, do not disassemble the product by yourself. Please contact
- Philips or Philips authorized service centers for help. $\ \, \spadesuit$ The lifespan of the UVC light is 8,000 hours, but the actual lifespan may vary
- $\ \, \blacklozenge \$ If the power cord is damaged, it must be replaced by a professional from the
- Power connections must be handled by an electrical professional. The protection grade of this product for touching live parts is Class 1. A leakage protection switch with large opening distance (contact opening distance of more than 3mm) and 30mA all-pole disconnection must be installed in the power supply line.


Product overview

7. Flat head stainless steel self-tapping screws 1. Host


2. End cover of host 8. Rubber rings for clothes poles

3. Scissor frame 9. Bed sheet pole seat 10. Extendable bed sheet pole 4. Wire rope

5. Pole seat 11. Joint bar 6. Extendable clothes pole



Remote control instruction



Press to lift the drying rack. The rack will stop automatically at top (upper limit). Stop Press to stop the lifting or descending drying rack. Press to drop the drying rack. The rack will automatically stop at bottom Down (lower limit). Power ower up the drying rack or cut power off. Press to turn on LED lamp. Press again to turn it off. LED lamp will turn off utomatically after 2 hours if not being turned off manually ◆ Instant Disinfection: Press the disinfection button, and the clothes rack will immediately rise to the top and activate the disinfection function. Press the button again to deactivate the disinfection function. If the disinfection function is enabled and not manually turned off, the system will utomatically disable it after 37.5 minutes of operation • Pre-disinfection: Press and hold the disinfection button for more than 5 seconds, and the buzzer will sound continuously, indicating the entry into pre-disinfection mode. The clothes rack will immediately rise to the top and automatically activate the disinfection function after 8 hours. If the fection function is enabled and not manually turned off, the system will utomatically disable it after 37.5 minutes of operation ◆ Both pressing the disinfection button or the descent button can manually tivate the instant disinfection or pre-disinfection function ◆ Standard mode: press "Air drying", the drying rack wi**ll** automatica**ll**y rise to top and start air drying. Press again to stop it. Air drying will stop automatically after 2 hours if not being stopped manually. ◆ Enhanced mode: long press "Air drying" for 5 seconds, there will be a long beep, indicating the drying rack has entered into enhanced mode. The rack will automatically rise to top to start air drying. Press "Air drying" again to stop it. Air drying will stop automatically after 4 hours if it's not stopped Press "Air drying" or "Down" can both shut air drying off. ◆ Standard mode: press "Heat drying", the drying rack wi**ll** automatica**ll**y rise to top and start heat drying. Press again to stop it. Air drying will stop utomatically after 2 hours if not being stopped manually, 20 seconds after which the fans will also stop working. ◆ Enhanced mode: long press "Heat drying" for 5 seconds, there will be a long beep, indicating the drying rack has entered into enhanced mode. The rack will automatically rise to top to start heat drying. Press "Heat drying" again to stop it. Air drying will stop automatically after 4 hours if not being

opped manually, 20 seconds after which the fans will also stop working.

◆ Press "Heat drying" or "Down" can both shut air drying off.



Kind reminder:

This user manual is used as a guide. The photos, pictures, or illustrations provided in the manual are for explanation purposes, which may differ from the specific product, please refer to the actual product. Due to product version upgrade or other needs, Philips may update this manual timely without notice. If you need the latest version of the manual, please download it from the Philips website (www.philips.com/support). The copyright of any part from this manual, including text, pictures or illustrations, belongs to Philips. Without written permission, no corporation or individual may extract conv. translate or modify all or part of this or individual may extract, copy, translate, or modify all or part of this manual in any way. Unless otherwise agreed, Philips does not make any express or implied representations and guarantees.

Shenzhen Yunyue Intelligent Technology Co., Ltd. Address: Room 901, Block A, Huahan Innovation Park, Nanshan District,

Shenzhen, Guangdong, P.R.C.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

This product has been manufactured by and is sold under the responsibility of Shenzhen Yunyue Intelligent Technology Co., Ltd. and Shenzhen Yunyue Intelligent Technology Co., Ltd. is the warrantor in relation to this product.

To get product related support, please go to: www.philips.com/support.

Installation instruction

- 1. Please prepare following tools before installation, including cutting pliers, hammer, Phillips screwdriver, 10~14# wrench, utility knife, tape measure, insulating gloves, insulating tape, marker, etc.
- 2. Choose a proper location for installing the drying rack and decide host

Fix expansion screws


- 1. If the chosen location is installed with lamp, turn it off and remove it first.
- 2. Measure dimension and mark the installation location on ceiling.
- 3. As shown in Figure 1, paste the installation template on marked location at ceiling, then use a marker to mark out four holes.
- 4. As shown in Figure 2, drill 4 φ10×60 mm holes, fix and tighten expansion screws with a wrench. Loosen nuts of two expansion screws at one side and keep about 5 mm distance between washer and nut. Remove nuts and washers of 2 expansion screws on the other side.






Install host

- 1. As shown in Figure 3, carefully hold the host and fix it with expansion screws
- 2. Connect power cables correctly, (Note: connect brown wire of host power cable to live wire, blue to neutral wire, yellow and green to grounding wire), then wrap the connected wires with insulating tape and put it in the gap between host and the ceiling.




1. As shown in Figure 4, buckle pulley of scissor frame into the chute of mounting plate and lock it with screws.


2. As shown in Figure 5, pass the wire rope through positioning ring, then place the end part of wire rope in retainer and lock it with retainer cover




正折

- 1. As shown in Figure 6, remove screws from pole seat, align the vacant position of the clothes pole with the support plate, and fix with screws.
- 2. As shown in Figure 7, unfasten the screws securing clothes poles and bed sheet poles and mount parts in following order, screw plugs, cover of clothes poles and bed sheet poles, joint bar and washer, then fix all with set screw and finally mount the cover of joint bar.





- 3. As shown in Figure 8, take bed sheet pole down when you need to dry bed
- 4. As shown in Figure 9, when the bed sheet pole is not needed, it can be folded and put back to pole seat



Remote control programming instruction

◆ Program the remote control before use it.

反折

Programming: unplug host power and replug it after 10 seconds, after which the buzzer will have a long beep. Following the beep, press "Up" and "Down" at the same time and the buzzer will beep for 3 times, indicating successful programming.

Function test instruction

- ♦ Down: press "Down" and observe whether the drying rack can automatically stop after dropping at 1.1 m.
- ♦ Up: press "Up" and observe whether the drying rack can automatically stop after reaching to the top.
- ♦ Lighting: press "Lighting" and observe whether the LED lamp can be turned
- ♦ Disinfection: press "Disinfection" and observe whether the UVC lamps work
- ♦ Air drying: press "Air drying" and observe whether air drying function works
- ♦ Heat drying: press "Heat drying" and observe whether the heat drying function works normally.
- ♦ Push to lift: slightly push pole or pole seat upward, then let go and see whether the drying rack will automatically rise.
- ♦ Hold to stop: hold up the dropping pole or pole seat of the drying rack to observe whether it stops immediately.
- Troubleshooting

Failure	Possible reasons	How to solve		
Remote control does not work	The host is not powered; low battery of remote control; remote control is not programmed.	Power on host; replace batteries of remote control; re-program remote control		
Drying rack stops	Drying rack encounters resistance	Remove objects causing		
sudden l y	and triggers obstacle detection switch;	resistance; wait for motor to		
during running	motor's self-protection from overheating.	cool down before start it again		
LED lamp	The host is not powered;	Power up the host;		
doesn't work	LED lamp is damaged.	replace LED lamp.		

Warranty card

正折

Relevant information				
User name		Contact of user		
Address of user				
Product name		Model of product		
Serial number		Invoice No.		
Se ll er name		Date of sales		
Se ll er address				

e ll er address				
Maintenance records				
Date	Issue	Maintenance staff	User signature	

PHILIPS 1000 Series

Smart drying rack

SDR105

反折



User manual

 $\label{please read this user manual carefully before using this product. \\$

Thank you for purchasing Philips-branded products. For your safety, please read this user manual carefully before using the product. Any personal injury, property or other loss caused by not following the user manual or precautions, no liability will be assumed by Philips.

PHILIPS		比例	1:1
		尺寸	100*200mm(成型)
名称	飞利浦SDR105智能晾衣架 用户手册	颜色	黑色(COMOYOK90)
		材料	105g双铜纸
日期	2023. 11. 16	设计	冯泽丹